

HIDDEN BRACKET FLOATING SHELF INSTALLATION INSTRUCTIONS

EACH SHELF IS WRAPPED AND HAS A CORRESPONDING HIDDEN BRACKET INSIDE.

REMOVE THE HIDDEN BRACKET FROM THE SHELF/SHELVES.

IMPORTANT: KEEP EACH BRACKET PAIRED WITH THE SPECIFIC SHELF IT WAS IN. THE BRACKETS MAY BE TIGHT IN THE HOLES. TURN OVER AND GENTLY SHAKE. A SCREWDRIVER OR CHISEL MAY ASSIST IN SLOWLY LIFTING AT EACH BRACKET EDGE.

NOTE: MOVE EACH EDGE SLOWLY AND IN SHORT DISTANCES. ATTEMPTING TO PRY ONE ENTIRE SIDE OUT MAY WEDGE THE OTHER SIDE DOWN AND MAKE REMOVAL MORE DIFFICULT.

DETERMINE WHERE THE SHELF IS TO BE LOCATED.

TO ATTACH THE BRACKETS TO THE WALL, LOCATE THE CORRECT POSITION ON THE WALL AND MARK THE SCREW HOLES IN THE BRACKET ON THE WALL WITH A PENCIL.

THE "TEETH" OF THE BRACKET FACE UP, TOWARD THE CEILING.

RECOMMENDED: ATTACH TO STUD. DRILL 1/8 INCH PILOT HOLES FOR SCREWS. IF ATTACHING TO DRYWALL (NO STUD), HEAVY-DUTY ANCHORS ARE ENCOURAGED.

SECURE THE BRACKET TO THE WALL WITH THE SCREWS PROVIDED.

INSTALL THE SHELF BY SLIDING THE SHELF ONTO THE BRACKET -- FITTING THE BRACKET INSIDE THE HOLES PRE-DRILLED ON THE BACK OF YOUR SHELF.

SCREW THE SMALL SET SCREWS INTO THE HOLES IN THE BOTTOM OF THE SHELF. THIS WILL SECURE THE SHELVES IN PLACE ON THE BRACKETS.

REPEAT PROCESS FOR ADDITIONAL BRACKETS / SHELVES.

DECORATE AS DESIRED, AND ENJOY!

CARE INSTRUCTIONS

DUST WITH A SOFT, LINT-FREE CLOTH. CLEAN SPILLS IMMEDIATELY USING A DAMP, SOFT CLOTH AND MILD SOAP, IF NECESSARY. DRY THOROUGHLY WITH A CLEAN, DRY CLOTH AS EXCESS MOISTURE CAN DAMAGE FINISH. J THOMAS HOME USES A PREMIUM TOP COAT FINISH ON ALL ITS WOOD SHELVES. WAXING YOUR SHELVES IS NOT NECESSARY.

VIDEO INSTALLATION INSTRUCTIONS

[HTTPS://YOUTU.BE/E2A5S3FKU3E](https://youtu.be/e2A5S3FKU3E)

SHARE YOUR STYLE!

TAG US ON FACEBOOK @JTHOMASHOME AND INSTAGRAM @JTHOMASHOMEGOODS

#MYJTHOMASHOME

#THINKHANDCRAFTED

LEAVE US A REVIEW

